Hardware

Why is the USB drive included in my server plan not displayed in the server data?

The USB sticks contained in sepcific EUserv server plans are not installed

by default on your server.

If the USB flash drive is not displayed in the server data after your server order

has been processed, please contact our support in writing under support@euserv.com

so our technicians can cause the installation of your server's USB flash drive.

Once your USB flash drive has been connected, please check by dmesg if the USB

drive has been detected. If you want to boot from the USB flash drive, the operating

system has to be re-initialized.

Unique solution ID: #1726

Author: EUserv Support

Last update: 2016-05-04 10:03